

APPENDIX B INSTALLATION PROCEDURES

Follow the installation procedures written in the Operator's Manual.
The additional information required for installation is given below.

B.1 PCB DIP SWITCH (S1) SETTING VERIFICATION

Refer to *Section 4.4.2. PCB No. 6363* for the DIP switch settings.

B.2 START UP SEQUENCE

After the initial power ON at installation, some system set up are required.

- (1) Priming sequence:
Access the "Setting Seq." program by selecting 9. Service - 2. Service Seq. - 1. Setting Seq.
Refer to *Section 5.5.1. Setting Sequence* of this manual for information.
- (2) Date setting:
Access the "Date/Time" program by selecting 6. Settings - 2. Date/Time.
Refer to *KX-21 Operator's Manual, Chapter 10* for information.
- (3) Cycle counter reset:
Access the "initialize" program by selecting 9. Service - 3. Settings - 1. Initialize - 1. Cycle Counter.
Refer to *Section 5.6.1. Initialize* of this manual for information.

NOTE: Cycle counter must be reset after setting the current date, since the date of last maintenance will also be reset.