

Audio/HiFi Service Manuals sorted by sets

Set	Service Manual	Set	Service Manual
APOLLO 2000	72010 760 7500	M 18-C	72010 755 8500
BEEZZ RRCD 4101	Exchange Set	M 19-C	72010 759 1500
Boy 47	Exchange Set	M 27-C	72010 752 2500
CCF 23	72010 755 6500	M 28-C	72010 755 8500
CD 21	72010 755 5500	M 29-C	72010 759 1500
CD 22	72010 755 5500	M 37-DC	72010 753 2500
CD 23	72010 756 3500	M 38-C	72010 755 8500
CDM 700	72010 755 7000	M 48-DC	72010 755 8500
CDM 800	72010 771 4500	M 49-DC	72010 759 4000
CDM 900	72010 771 5500	M 7-C	72010 752 2500
CDP 180	Exchange Set	MASQ RRCD 9100 PLL	72010 771 9500
CDP 210	72010 755 1500	Mpaxx M-P 150	Exchange Set
CDP 310	72010 757 8500	MPaxx MP100	72010 761 0000
CDP 410	Exchange Set	MPaxx MP150	72010 771 0500
CDP 440	Exchange Set	MPaxx SP 4101	72010 771 9000
CDP 76	72010 755 1000	MPaxx SP 9100 PLL	72010 771 9000
CDP-S 150	72010 752 7000	MS 4101	72010 771 7000
CDP-S 250	72010 757 1000	Music Boy 40 RP 4200	Exchange Set
CF 21	72010 755 6000	Music Boy 50 RP 5200	Exchange Set
City Boy 40	Exchange Set	Music Boy 50 RP 5240 LW	Exchange Set
City Boy 50 PR 5100	Exchange Set	Music Boy 51 RP 5201 PLL	Exchange Set
City Boy 52	Exchange Set	MYSTIXX CDP 9100 SPCD	72010 772 0500
Concert Boy 240	Exchange Set	MYSTIXX CDP 9200 SPCD	72010 772 3000
CR 120	Exchange Set	NOCTUS SC 9100 DCF RDS	72010 771 8500
CR 120 A	Exchange Set	Ocean Boy 350	Exchange Set
Ctiv Boy 31 PR 3201	Exchange Set	Ocean Boy 510	Exchange Set
FREAXX 10 RRCD 4303	Exchange Set	PA 5 - TurNiT	72010 758 0500
FREAXX 20 RRCD 4202	72010 772 3500	PA 6	72010 760 7000
FREAXX 30 RRCD 4203 PLL	72010 772 4500	PLANIXX CDP 4103 AS 10	Exchange Set
FREAXX 40 RRCD 4204 PLL	72010 772 5000	PLANIXX CDP4104 AS 40 PLL	Exchange Set
FREEZZ 10 RRCD 4300	Exchange Set	Prima Boy 100	Exchange Set
FREEZZ 20 RRCD 4301 PLL	Exchange Set	Prima Boy 80	Exchange Set
K-CDP 66	72010 755 0500	R 21	72010 755 9000
K-RCD 120	72010 756 5000	R 22 DPL	72010 755 9000
KM 12	72010 754 3000	R 23 DPL	72010 757 2000
KM 13	72010 757 1500	RBX-1	72010 752 2000
M 100 A	72010 749 7500	RCD 2000	72010 760 6000
M 100 ADPL	72010 750 6500	RCD 405	72010 752 3000
M 100 CDC	72010 750 7000	RR 276 / L	Exchange Set
M 100 CF	72010 749 8500	RR 300 CD	72010 760 5000
M 100 R	72010 749 7500	RR 315	Exchange Set
M 100 T	72010 750 6000	RR 316 / L	Exchange Set
M 100-CD MKII	72010 754 3500	RR 420 CD	72010 752 4000
M 14	72010 759 4500	RR 430 CD	72010 760 0000
M 17-C	72010 752 2500	RR 440 CD	72010 771 1500

Observe also the instructions given in the "Safety" Service Manual Part No. 72010 800 0000!

Set	Service Manual
RR 440 CD	Exchange Set
RR 630 CD	72010 759 3000
RR 640 CD	72010 771 0000
RR 660 CD	72010 759 3000
RR 670 CD	72010 771 0000
RR 720 CD	72010 759 3500
RR 740 CD	72010 771 1000
RR 760 CD	72010 759 3500
RR 770 CD	72010 771 1000
SC 900	72010 754 4500
SC 910	72010 754 4000
Sonoclock 13	Exchange Set
Sonoclock 13/ L	Exchange Set
Sonoclock 186	Exchange Set
Sonoclock 186	Exchange Set
Sonoclock 22	Exchange Set
Sonoclock 30 SC 3300	Exchange Set
Sonoclock 30 SC 3300	Exchange Set
Sonoclock 30 SC 3340 LW	Exchange Set
Sonoclock 32	Exchange Set
Sonoclock 42	Exchange Set
Sonoclock 420	Exchange Set
Sonoclock 50 SC 5300	Exchange Set
Sonoclock 50 SC 5340 LW	Exchange Set
Sonoclock 51 SC 5301	Exchange Set
Sonoclock 52 SC 5302	Exchange Set
Sonoclock 55 SC 5305	Exchange Set
Sonoclock 620	Exchange Set
Sonoclock 690	Exchange Set
Sonoclock 720	Exchange Set
Sonoclock 740	Exchange Set
Sonoclock 755	Exchange Set
Sonoclock 755	Exchange Set
Sonoclock 890	Exchange Set
SQUIXX CDP 4100	Exchange Set
SQUIXX CDP 4101 AS 10	Exchange Set
SQUIXX CDP 4102 AS 40	Exchange Set
SQUIXX CDP 4200 AS 45	Exchange Set
ST 16 (ADR)	72010 752 1000
T 22	72010 755 4000
TurNiT - PA5	72010 758 0500
UMS 100	72010 771 6000
UMS 11	72010 757 2500

Set	Service Manual
UMS 12	72010 757 2500
UMS 12-S	72010 757 2500
UMS 15	72010 760 8500
UMS 200	72010 771 7500
UMS 25	72010 760 9500
UMS 4100	72010 771 8000
UMS 4101	72010 771 8000
V 14 DPL-RF	72010 752 1500
V 21	72010 755 4500
V 23	72010 755 5000
VARIXX UMS 4200	72010 772 2500
VERTIGA UMS 5100	72010 772 0000
VERTIGA UMS 5101 CDC	72010 772 2000
Yacht Boy 208	Exchange Set
Yacht Boy 218	Exchange Set
Yacht Boy-P2000	72010 757 0000

Car Audio Service Manuals sorted by sets

Set	Service Manual
Advance CC	72010 760 4000
Advance CD	72010 760 4500
BOOSTER PA 120	72010 731 9500
BOOSTER PA 240	72010 732 0000
EC 4000 RDS	72010 748 5000
EC 4200 RDS	72010 759 2000
EC 4290 CD	72010 750 5500
EC 4490 CD	72010 759 2500
EC 4600 RDS	72010 752 7500
EC 4700 RDS	72010 760 1500
EC 4790 CD	72010 760 2000
EC 4890 CD	72010 771 2000
EC 7400 RDS	72010 739 5000
EC 7500 RDS	72010 739 5000
MCD 20	72010 733 6000
MCD 30	72010 737 2500
MCD 36	72010 748 3000
MCD 40	72010 748 3000
MCD 46	72010 771 2500
MCD 50	72010 771 3000
SCC 3400 RDS	72010 771 4000
SCC 3460 RDS	72010 771 4000
SCC 5460 RDS	72010 772 1000
SCD 1590 VD	72010 739 1000
SCD 1910 RDS	72010 733 2000
SCD 3390 RDS	72010 757 8000
SCD 3490 RDS	72010 771 4000
SCD 3590	72010 739 1000
SCD 3590 RDS	72010 771 4200
SCD 5290 RDS	72010 749 3500
SCD 5390 RDS	72010 749 4500
SCD 5410 DAB	72010 772 4000
SCD 5490 RDS	72010 772 1000
SCD 5690 RDS	72010 749 4500
WKC 1630	72010 744 9500
WKC 1650 VD	72010 736 1000
WKC 1670 VD	72010 738 7000
WKC 1700 VD	72010 791 8500
WKC 1701 VD	72010 791 8500
WKC 1903 RDS	72010 731 0500
WKC 1904 RDS	72010 736 0500
WKC 2201 RDS	72010 758 6000
WKC 3200	72010 752 4500
WKC 3201	72010 752 4500
WKC 3300	72010 752 4500

Set	Service Manual
WKC 3301	72010 752 4500
WKC 3600	72010 749 1500
WKC 3630	72010 744 9500
WKC 3650	72010 736 1000
WKC 3700	72010 730 6000
WKC 3700 R	72010 730 6000
WKC 3701	72010 740 2000
WKC 3701 R	72010 730 6500
WKC 3904 RDS	72010 731 8000
WKC 3905 RDS	72010 731 8500
WKC 5100	72010 746 3500
WKC 5101	72010 746 3500
WKC 5200	72010 746 3500
WKC 5201	72010 746 3500
WKC 5300	72010 746 3000
WKC 5600	72010 746 3000
WKC 6400 RDS	72010 740 0000
WKC 6500 RDS	72010 740 0000

Observe also the instructions given in the "Safety" Service Manual Part No. 72010 800 0000!